
CHAPTER 18


Management Setup

18.1 Introduction

By default, the router may be configured and managed through any Telnet client or Web browser running on any operating system. There is no requirement for additional software or utilities. However, for some specific environments, you may want to change the server port numbers for the built-in Telnet or HTTP server, create access control lists to protect the router, or reject the system administrator to login from the Internet.

18.2 Configuration

Click **Management Setup**. The following setup page will appear on your computer screen.



System Management > Management Setup

Management Access Control

- Enable remote firmware upgrade(FTP)
- Allow management from the Internet
- Disable PING from the Internet

Access List

List IP	Subnet Mask
1	<input type="text"/> <input type="text"/>
2	<input type="text"/> <input type="text"/>
3	<input type="text"/> <input type="text"/>

Management Port Setup

- Default Ports (Telnet:23, HTTP:80, FTP:21)
- User Define Ports

Telnet Port :

HTTP Port :

FTP Port :

SNMP Setup

- Enable SNMP Agent

Get Community :

Set Community :

Manager Host IP :

Trap Community :

Notification Host IP :

OK

Copyright (c) 2004, DrayTek Corp. All Rights Reserved.

18.2.1 Management Access Control

Enable remote firmware update (FTP): Check the checkbox to allow remote firmware upgrade through FTP (File Transfer Protocol).

Allow management from the Internet: Enable the checkbox to allow system administrators to login from the Internet. By default, it is not allowed.

Disable PING from the Internet: Check the checkbox to reject all PING packets from the Internet. For security issue, this function is enabled by default.

18.2.2 Access List

You could specify that the system administrator can only login from a specific host or network defined in the list. A maximum of three IPs/subnet masks is allowed.

IP: Indicate an IP address allowed to login to the router.

Subnet Mask: Represent a subnet mask allowed to login to the router.

18.2.3 Management Port Setup

Default Ports: Check to use standard port numbers for the Telnet and HTTP servers.

User Defined Ports: Check to specify user-defined port numbers for the Telnet and HTTP servers.

18.2.4 SNMP Setup

Enable SNMP Agent: Check the checkbox to enable built-in SNMP agent.

Get Community: Specify a string to identify the management communities for the SNMP GET command.

Management Setup

Set Community: Specify a string to identify the management communities for the SNMP SET command.

Manager Host IP: Specify the IP address of the SNMP manager station.

Trap Community: Specify a string to identify the management communities for the SNMP TRAP notifications.

Notification Host IP: Specify the IP address of the station that wants to receive the TRAP notifications.